

WI-FI WATERPROOF TWIN SOCKET IP66



1 Installation

Parameter	
Model	SHA5274
Rated Voltage	90V-250V AC
Max Current	13A Gang
Wireless Standard	WI-FI 2.4Ghz
Material	PC

1. Install ENERSMART app into smart phone or tablet device. Or scan the QR code, download and install into smart phone or tablet device. Also works with Amazon Alexa & Google Home.

Download Our App

ENERJSMART
To download, Scan the QR code

Android

iOS

Google Home

WORKS WITH amazon alexa

2. Power up: On/Off operating principle. The connected appliances work/stop through live wire power on/off.
3. Cut off the power. Use screw driver to open the rear cover. Connect the wires correctly. Install and power it up.



1. Reset function (Hold for 10 seconds).
2. USB Port.

4. Set up: Press and hold any button (switch) for 10 seconds till the LED Indicator flashes rapidly.

Input your WI-FI SSID and password

When the green light keeps on, the device is online. Start to control now!

2 Installation Diagram

1. Products and accessories display
2. Use a screwdriver to pry the panel
3. As is shown in
4. Noted
8mm
Cut the wire around 8mm
5. Connect the wire to the appropriate location
6. Tighten the two screws, the installation is complete