ENER-J®
Smart Home Living WiFi

MOTION SENSOR
INSTRUCTION

Product configuration

- Code button
- Inductive area
- Battery
- LED Light
- Holder

- Holder
- Sticker
- Screw stopper
- Screw

Reset:

(1) Press the reset button for 6 seconds till the indicator flash rapidly.Then device turns to smart wifi mode.

(2) Press the reset button again for 6 seconds till the indicator flash slowly. The device turns to AP mode.

Specifications

Battery:CR123A-3V X 1
Standby current:13uA
Operate current:120mA-130mA
Standby time:5 years
Operate time:1 year (15 times/day); 2 years (7 times/day)
Wireless type:2.4GHz
Wireless standard:IEEE 802.11b/g/n
Wireless range:45M
Sensitive distance:4-6M
Operating Temperature:0℃～40℃ (32°F～104°F)
Operating Humidity: 20%～85%
Storage Temperature:0℃～60℃ (32°F～140°F)
Storage Humidity:0%～90%
Size:50mm x 48mm x 48mm

Download App

1. Android phone:Download "ENERJSMART" from Google play store
2. IOS device:Download "ENERJSMART" from APP store.

ENERJSMART   Android   iOS

Register and login

1. Run "ENERJSMART"from your smartphone.
2. Register and login

---

Add Device

Select the item that you want to add, add the device via Smart WiFi or AP mode.


Network Configuration

1. Smart WiFi Mode:
Pressing the resetting button for 6s, the LED will rapidly blink.that is Smart Wifi mode.

2. AP mode:
Pressing the resetting button for 6s after the LED blink slowly,the device is in AP model to configurate the network.


Main function

1. Operate status, alarm | normal (device react time gap is about 1 minute, means device can only be triggered once in 1 minute)
It takes 3-5 seconds to receive the push notification after the device triggers.

---

2. Alarm recording(click"HISTORY")
3. Turn on and turn off the alarm (click"NOTICE". No any alarm push notification,only alarm record)


Alarm recording   Turn on/off the alarm

4. Linkage setting: connect 2 devices via scene setting.

Device Sharing

Device Sharing : Allow others to control the device by sharing device(note:you can delete the sharing in profile setting)


Push Notification

Enable to turn off .

Remove device

Take out the battery and then install it,wait for about 10-20 seconds to add device again,if device reset failed.

LED State

Device Status	LED State
Smart Wi-Fi	Indicator flashes quickly
AP mode	Indicator flashes slowly
Triggered	LED will rapidly blink,and OFF after scheduled time
suspend mode	Indicator off
Reset	Indicator lights up for 4s and after 2 seconds lights off, device goes into configuration mode

---

WiFi
Make Your Home Smarter